

Quick Start

Getting to Know Your Phone

Setting up Your Phone


Phone Basics

Touch Screen and Navigation




Insert the SIM card and battery

- 1 Push the back cover up to unlock it.




- 2 Lift up the back cover from the bottom side and remove.




- 3 Take the battery out of the plastic pouch.

- 4 Insert the SIM card (gold contacts facing down).



- 5 Insert the battery with its exposed copper contacts into the phone first.




- 6 Replace the back cover.

Charge the battery

- 1 Connect the USB cable to your phone.
- 2 Plug in the power adapter to an electrical outlet to start charging.

Turn on your phone

Press and hold the power button on the top panel.



Setup wizard

The first time you turn on your phone, you'll be guided to transfer contacts, set up your email and social network accounts, and more.

Be sure to sign in to your Google™ Account to use Google apps such as Gmail™ and Android Market™ on your phone.

Lock and unlock the screen

To lock, briefly press the power button.

To unlock, press the power button, then pull the ring up.



Navigate your phone

- Use your fingertip to lightly tap the screen and select options.
- Use quick flicks of your finger to scroll up/down and left/right.
- **All Apps Key:** Opens a screen to all of your applications.
- **Home Key:** Takes you to the main Home screen.
- **Menu Key:** Opens a menu with more options for the current screen.
- **Back Key:** Returns to previous screen.
- **Q Search Key:** Opens Google Search or allows you to search within an open application.
- **Notification bar:** Shows you timely information, like new message and Facebook notifications, missed calls, and calendar reminders. Touch the bar and slide it down with your finger to see full details. Press the **Back** key to close the bar.



Slide your finger horizontally to the left or right and you'll discover more space for adding icons, widgets, and more.



Find More Information

On the Web

- Interactive web tutorials are available at att.com/Tutorials. Select Manufacturer: **HTC** and Model: **Vivid** from the drop down menus.
- Detailed support information is available at att.com/DeviceSupport.
- For information about your wireless account or network, visit att.com/Wireless.

On the Phone

Call AT&T Customer Care at 1-800-331-0500 or dial 611 from any AT&T mobile phone.

Find Accessories

Accessories for your smartphone are available at att.com/WirelessAccessories or visit your local AT&T store.



©2011 AT&T Intellectual Property. All rights reserved. All other marks contained herein are property of their respective owners.
Accessories sold separately.
Printed in Taiwan

Personalization

Customize your phone

Customize your phone with wallpapers, widgets, app shortcuts and ringtones.


- From the main Home screen, tap to access customization options.
- Tap the option that you want to change, such as the wallpaper or the ringtone.
- Select from the options, and then save your preference.

Manage Home Screens

You have up to seven Home screens that you can add widgets and shortcuts on.

To add a Home screen item, tap and then choose a widget or a shortcut.

To move or remove Home screen items, press and hold and then drag as needed.



Call and Voicemail

Quickly make a call, answer a voicemail or add a contact with just a few taps.

Make a phone call

- On the Home screen, tap **Phone**.
- Enter a phone number or tap a contact from the list.
- Tap **Call**.
- To hang up, tap **End**.

Check your voicemail messages

- On the Home screen, tap **Phone**.
- Press and hold the number 1 key on the keypad.
- Follow the voice prompts.




Text Messaging

Send a text message

- From the Home screen tap > **Messages**.
- Tap to compose a new message.
- Enter a number or tap to browse your contacts.
- Tap the **Add text** field and then enter your message.
- Tap **Send**, or press to save the message as a draft.


Attach a picture or video

- While composing a text message, tap .
- Tap **Picture** or **Video**.
- Tap **Gallery** to choose a picture or video from an album, and then tap an item to attach it.
- Tap **Send**.



Pay per use charges apply unless you have a Messaging Plan.

Network Notifications



Your 4G LTE wireless device will display a network indicator to let you know which of AT&T's wireless networks you are connected to. A network indicator does not necessarily mean that you will experience any particular upload or download data speeds. Actual speeds depend upon a variety of factors, including the device, network utilization, file characteristics, terrain, etc. Learn more at wireless.att.com/learn/articles-resources/wireless-terms.jsp

- Connected to AT&T's 4G LTE network.
- Connected to AT&T's HSPA+ network. AT&T's HSPA+ network is capable of delivering 4G speeds when combined with enhanced backhaul. Your wireless device cannot distinguish between HSPA+ cell sites combined with enhanced backhaul and those without enhanced backhaul. Enhanced backhaul is available in limited areas. However, availability is increasing with ongoing backhaul deployment. Learn more at att.com/network.
- Connected to AT&T's EDGE/2G network.

Limited 4G LTE availability in select markets. 4G speeds delivered by LTE, or HSPA+ with enhanced backhaul, where available. Deployment ongoing. Compatible device and data plan required. LTE is a trademark of ETSI. Learn more at att.com/network

Internet

Browse the Web

① From the Home screen, tap  > **Internet**.

② Use your fingers to pinch or spread the screen to zoom in and out.

③ To visit another website, tap the address bar, enter the web address, and then tap .

④ To close the web page, tap .

Internet Options

Press  to view options:

- **Back** – Go back to previous webpage.


- **Forward** – Go forward to most recent webpage.

- **Add Bookmark** – Create bookmark for current webpage.

- **Bookmarks** – View and add bookmarks, see your browsing history and most-visited sites list.

- **Windows** – Show all open windows. To open additional windows, tap .

- **More** – View other options.



Email

If you signed in to your Google Account when you first set up your phone, you'll be able to send and receive Gmail messages. From the Home screen, just tap  > **Gmail**.

Set up email

① From the Home screen tap  > **Mail**.

② Choose the type of email account to set up.

③ Enter the **Email address** and **Password** for your email account.

④ Follow the onscreen instructions to complete setup.

Send an email

① From the Home screen tap  > **Mail**.

② Select the email account that you want to use.

③ On the email account inbox, tap .

④ Fill in one or more recipients.

⑤ Enter the subject and your message.

⑥ To add an attachment, press  and tap **Attach**.

⑦ Tap **Send**, or to send it later, tap **Save**.

Camera

Take a picture

① From the Home screen, tap  > **Camera**.

② To zoom in and out, slide your finger on the zoom bar .

③ Tap  to take the picture.

Send a picture

After taking a picture, tap  to share via Bluetooth™, send by email, send as a message, or upload to a social network.



Video

Record a video

① From the Home screen, tap  > **Camcorder**.

② Tap  to start recording video.

③ Slide your finger up or down on the zoom bar to zoom in and out while recording.

④ Tap  again to stop recording.

Trim a video

① From the Home screen, tap  > **Gallery**.

② Browse for and play the video you want to edit.

③ Press  and then tap **Trim**.

④ Drag the two trim sliders to the part where you want the video to begin and end.

⑤ Tap **Done**.

The trimmed video is saved as a new file. The original video remains unedited.



Social Networks

Facebook® and Twitter™ for HTC Sense

① From the Home screen, press , and then tap **Settings > Accounts & sync**.

② Tap **Add account > Facebook for HTC Sense**, enter your log in credentials, and then tap **Sign in**.

③ Tap **Add account > Twitter for HTC Sense**, enter your log in credentials, and then tap **Sign in**.

AT&T Services

Featured services

The following services are available for your HTC Vivid:

 **AT&T Code Scanner:** Reads UPC, QR and Data Matrix barcodes. Scan, Shop, Save.

 **AT&T FamilyMap:** Use this subscription service to easily locate a family member's wireless phone on a map from your device. To sign up for this service, visit att.com/familymap.

 **AT&T NavigatorSM:** Get traffic updates, GPS navigation and turn-by-turn voice directions.

 **Live TV:** Watch LIVE, on-demand and downloadable mobile TV including ESPN Mobile TV, Fox News and more.

 **myAT&T:** Access billing, usage and feature information as well as manage your account from the palm of your hand.

 **YPmobile:** Use text or voice search to find businesses and events near your location.

Some services may require a separate subscription and incur data usage. AT&T U-verse Live TV requires mobile broadband service. Service not available in all areas. Programming subject to blackout restrictions. Download and watch capability available for select content, requires Wi-Fi connection and is available for viewing for limited time periods.

Bluetooth®, Wi-Fi® and Mobile Hotspot

Pair with another Bluetooth device

- ① From the Home screen, press .
- ② Tap **Settings > Wireless & networks > Bluetooth settings**.
- ③ Select the **Bluetooth** check box to turn Bluetooth on, and then tap **Scan for devices**.
- ④ Tap the device name you want to connect to.

Connect to a Wi-Fi network

- ① From the Home screen, press .
- ② Tap **Settings > Wireless & networks > Wi-Fi settings**.
- ③ Select the **Wi-Fi** check box to turn Wi-Fi on.
- ④ Choose a Wi-Fi network and then tap **Connect** (secured networks require a passkey).

Share your connection (Tethering and Mobile Hotspot*)

- To use tethering, attach the device you want to tether to your phone with a USB cable. When prompted for the connection type, tap **USB Tethering**.
- To enable a portable hotspot, from the Home screen, press . Tap **Settings > Wireless & networks**. Tap **Portable Wi-Fi Hotspot** to turn on. Set a password upon first use.


*Requires a minimum of DataPro 4GB plan.

Android Market™

Android Market is the place to go to find a variety of free and paid apps for your phone.

Find and install an app

- ① From the Home screen, tap  > **Market**.
- ② Browse by featured apps or by category, or search for the app you want.
- ③ Tap the app to select it.
- ④ To download or purchase, tap **FREE** or the price button under Buy.
- ⑤ If you agree to the conditions, tap **OK** to begin downloading and installing the app.



A Google Checkout payment method is required to purchase a paid app.

Calendar


Access your calendar

Use the Calendar app to schedule your events, meetings, and appointments. Sign in to your Google, Microsoft Exchange ActiveSync®, or Facebook accounts to see your calendars from these accounts.

- ① From the Home screen, tap  > **Calendar**.
- ② Switch between different calendar views by tapping the bottom tabs.

Set a new appointment

- ① On any Calendar view, tap .
- ② If you have more than one calendar, select the calendar in which to add the event.
- ③ To invite people to your event, tap  and then choose from your contacts.
- ④ Enter the event details, such as the date and time.
- ⑤ Tap **Save**.



Contacts

The People app combines your contacts from accounts like Google, Facebook and Exchange Active Sync. You can manually add contacts as well.

Add a new contact

- ① From the Home screen tap  > **People**.
- ② On the All tab, tap .
- ③ In the **Name** field, enter the contact name.
- ④ Select the Contact type, for example Google.
- ⑤ Enter the contact information.
- ⑥ Tap **Save**.

